## Product Display

(Note: The floor stand,microphone, shock mount and pop filter is not includ in the product and the customer needs to prepare it himself)

3.Use with floor stand(3/8 interface)

❶ Step1:Take out the isolation shield and all accessories

❷ Step2:Take out the floor stand.(The product does not include a floor stand)

❸ Step3:Combine the nut,washer,connecting rod and adapter (the connecting rod can move forward and backward to adjust the position)

❹ Step4:Fix the Isolation Shield on the floor stand（as the picture shows）

After passing the floor stand through the crossbar and washer of the soundproof cover, tighten it with a nut

The connecting rod can move forward and backward to adjust the position

Floor stand with 3/8 interface (The product does not include)

AOKEO

USER MANUAL
ISOLATION SHIELD

Please read the manual carefully before use

## 2.Use with floor stand(5/8 interface)

❶ Step1:Take out the isolation shield and all accessories

❷ Step2:Take out the floor stand.(The product does not include a floor stand)

❸ Step3:Combine the nut,connecting rod and adapter (the connecting rod can move forward and backward to adjust the position)

❹ Step4:Install washer, screws and nut on the crossbar of the isolation shield

❺ Step5:Fix the Isolation Shield on the floor stand（as the picture shows）

After passing the floor stand through the crossbar and washer of the soundproof cover, tighten it with a nut

The connecting rod can move forward and backward to adjust the position

Floor stand with 5/8 interface (The product does not include)